



INFUSED™

Concrete Stain

PRODUCT APPLICATION GUIDE

INFUSED™ is a neutral based stain used for staining concrete, antiquing and highlighting concrete and decorative overlay surfaces. INFUSED™ concrete stain is designed to be used with ColorShade™ universal colorant.

Tools Needed:

Pump up sprayer, cyclone mixer, high speed drill, clean mixing pail, clean measuring container.

Application:

Step 1. Measure out desired amount of clean, potable water in a measuring container.

Step 2. Add desired amount of ColorShade™ universal pigment to water and mix with cyclone mixer and high speed drill for several minutes to ensure complete pigment dispersion. This happens by shearing or slicing the pigment particles.

Step 3. Add desired amount of INFUSED™ concrete stain and mix again for 20-30 seconds.

Step 4. Pour mixed contents into clean pump up sprayer and pump up tightly.

Step 5. Spray contents onto surface to be stained at a rate of approximately 200-300 square feet per diluted gallon. Be sure to shake sprayer periodically to avoid settling.

Step 6. Allow INFUSED™ concrete stain to dry before proceeding to next step.

Step 7. Clean up with soap and water.

Disclaimer: The info herein is general to assist our customers in determining whether TruCrete Surfacing Systems® products are suitable for their specific applications. TruCrete Surfacing Systems® products are intended for sale to trained installers. We recommend that customers inspect and test our products before use to satisfy themselves as to the content and suitability for the applications they intend to use TruCrete Surfacing Systems® products for. **Nothing herein shall constitute any warranty expressed or implied, including any warranty of merchantability or fitness for a particular purpose**, nor is any protection from any law or patent to be inferred. The exclusive remedy for all proven claims is replacement of our materials and in no event shall we be liable for incidental or consequential damages.

TruCrete Surfacing Systems® All Rights Reserved

TruCrete Surfacing Systems®
5203 Poplar Dr. Cambridge, MD 21613
443-205-4547
www.trucrete.com